



FRONT PANEL



- [1] Active bass instrument INPUT [JACK 6.3mm].
- [2] Passive bass instrument INPUT [JACK 6.3mm].
- [3] GAIN control True/Boost.
- [4] BASS control with MLO-system.
- [5] Triple BASS switch to reduce or boost low frequency [DBS-cut/OFF/DBS-boost].
- [6] MIDDLE control.
- [7] PUNCH triple switch High-Punch/off/Low=Punch
- [8] TREBLE CONTROL with MLO-system.
- [9] Triple TREBLE switch to reduce or boost high frequency [CUT/OFF/PRESENCE].
- [10] VOLUME control.
- [11] MUTE on/off switch.
- [12] ON/MUTE indicator.
- [13] Power amplifier CLIP indicator.
- [14] STANDBY and PROTECTION indicator.

REAR PANEL



- [1] Balanced LINE OUTPUT [XLR].
- [2] SPEAKERS output [combo SPEAKON and 6,3mm JACK].
- [3] LINE OUTPUT PRE/POST EQ switch.
- [4] LINE OUTPUT GROUND LIFT switch.
- [5] POWER switch.
- [6] EC POWER INPUT socket with AC fuse.